

6U Open VPX BACKPLANE BKP6-DIS05-11.2.16-4


VITA 46
VITA 65




Key figures:

- Compliant to VITA 46.0 baseline specification
- Compliant to VITA 65 , BKP6-DIS05-11.2.16-4
- 5 Slots VPX, 5 Payload Slots
- X4 full mesh configuration (4 FPs)
- M3 studs for main voltage power entry
- PCB size 261.85 mm x 123.85mm x 5.4 mm
- 5 HP from slot to slot (25.40 mm) 1"
- Flexible keying and alignment mechanism
- with geographical address pins
- Reference clock
- Auxiliary clock
- System Reset
- With JTAG connector on first slot (JT1)
- System Management Interface on the backplane (I2CA, I2CB)
- Non-Volatile Memory Read Only signal set by Jumper BR1
- Battery backup option setting by Jumper XBAT for Vbat external or connected to 3.3VAUX.
- Max. Input current per backplane :
VS1:VS2:VS3 = 160A : 160A : 115A
- Operating temperature: -40°C - +85°C
- Storage temperature: -55°C - +85°C
- Flammability rating: UL94-V0
- RoHS compliant
- Custom assembly or modification on request

Front side



Rear side



▪ **Order number: B196501560**

6U Open VPX BACKPLANE
BKP6-DIS05-11.2.16-4


VITA 46
VITA 65



1) Topology: 5-Slot — BKP6-DIS05-11.2.16-4 (5 Payloads)

Profile Payload slots:

SLT6-PER-4F-10.3.1 / MOD6-PER-4F-12.3.1



2) Data Plane Port connections

Slot/ Channel		DP01	DP02	DP03	DP04
1	5-Slot Mesh Cluster 1	VPX02-DP01	VPX03-DP01	VPX04-DP01	VPX05-DP01
2		VPX01-DP01	VPX03-DP02	VPX04-DP02	VPX05-DP02
3		VPX01-DP02	VPX02-DP02	VPX04-DP03	VPX05-DP03
4		VPX01-DP03	VPX02-DP03	VPX03-DP03	VPX05-DP04
5		VPX01-DP04	VPX02-DP04	VPX03-DP04	VPX04-DP04


6U Open VPX BACKPLANE
BKP6-DIS05-11.2.16-4

VITA 46
VITA 65




3) Drawings

Front side



Back side



6U Open VPX BACKPLANE BKP6-DIS05-11.2.16-4

VITA 46
VITA 65



4) Pin Assignment

Pin Assignment VPX J0 (Utility Connector)

	Row i	Row h	Row g	Row f	Row e	Row d	Row c	Row b	Row a
1	Vs1	Vs1	Vs1	Vs1	No Pad*	Vs2	Vs2	Vs2	Vs2
2	Vs1	Vs1	Vs1	Vs1	No Pad*	Vs2	Vs2	Vs2	Vs2
3	Vs3	Vs3	Vs3	Vs3	No Pad*	Vs3	Vs3	Vs3	Vs3
4	GND	SM2	SM3	GND	-12V_Aux	GND	SYSRESET*	NVMRO	GND
5	GND	GAP*	GA4*	GND	3.3V_Aux	GND	SM0	SM1	GND
6	GND	GA3*	GA2*	GND	+12V_Aux	GND	GA1*	GA0*	GND
7	TCK	GND	GND	TDO	TDI	GND	GND	TMS	TRST*
8	GND	REF_CLK-	REF_CLK+	GND	GND	AUX_CLK-	AUX_CLK+	GND	GND

VS1=12V , VS2=12V , VS3=5V

Payload Slot Profile SLT6-PER-4F-10.3.1 — P1 & J1

Plug-In Module P1	Row G	Row F	Row E		Row D	Row C	Row B		Row A
Bplane J1	Row i	Row h	Row g	Row f	Row e	Row d	Row c	Row b	Row a
1	GDiscrete1	GND	GND-J1	DP01-T0-	DP01-T0+	GND	GND-J1	DP01-R0-	DP01-R0+
2	GND	DP01-T1-	DP01-T1+	GND-J1	GND	DP01-R1-	DP01-R1+	GND-J1	GND
3	P1-VBAT	GND	GND-J1	DP01-T2-	DP01-T2+	GND	GND-J1	DP01-R2-	DP01-R2+
4	GND	DP01-T3-	DP01-T3+	GND-J1	GND	DP01-R3-	DP01-R3+	GND-J1	GND
5	SYS_CON*	GND	GND-J1	DP02-T0-	DP02-T0+	GND	GND-J1	DP02-R0-	DP02-R0+
6	GND	DP02-T1-	DP02-T1+	GND-J1	GND	DP02-R1-	DP02-R1+	GND-J1	GND
7	Reserved	GND	GND-J1	DP02-T2-	DP02-T2+	GND	GND-J1	DP02-R2-	DP02-R2+
8	GND	DP02-T3-	DP02-T3+	GND-J1	GND	DP02-R3-	DP02-R3+	GND-J1	GND
9	UD	GND	GND-J1	DP03-T0-	DP03-T0+	GND	GND-J1	DP03-R0-	DP03-R0+
10	GND	DP03-T1-	DP03-T1+	GND-J1	GND	DP03-R1-	DP03-R1+	GND-J1	GND
11	UD	GND	GND-J1	DP03-T2-	DP03-T2+	GND	GND-J1	DP03-R2-	DP03-R2+
12	GND	DP03-T3-	DP03-T3+	GND-J1	GND	DP03-R3-	DP03-R3+	GND-J1	GND
13	UD	GND	GND-J1	DP04-T0-	DP04-T0+	GND	GND-J1	DP04-R0-	DP04-R0+
14	GND	DP04-T1-	DP04-T1+	GND-J1	GND	DP04-R1-	DP04-R1+	GND-J1	GND
15	Maskable Reset*	GND	GND-J1	DP04-T2-	DP04-T2+	GND	GND-J1	DP04-R2-	DP04-R2+
16	GND	DP04-T3-	DP04-T3+	GND-J1	GND	DP04-R3-	DP04-R3+	GND-J1	GND

6U Open VPX BACKPLANE BKP6-DIS05-11.2.16-4

VITA 46
VITA 65



Payload Slot Profile SLT6-PER-4F-10.3.1 — P2&J2 – P6&J6



This connectors are all User Defined pins. See Section VITA65 6.3.3 for requirements and pin assignments concerning connectors that are all User Defined.

Backplane Jn	Row i	Row h	Row g	Row f	Row e	Row d	Row c	Row b	Row a
1	UD	UD	UD	UD	UD	GND	UD	UD	UD
2	GND	UD	UD	GND	UD	UD	UD	UD	GND
3	UD	UD	UD	UD	UD	GND	UD	UD	UD
4	GND	UD	UD	GND	UD	UD	UD	UD	GND
5	UD	UD	UD	UD	UD	GND	UD	UD	UD
6	GND	UD	UD	GND	UD	UD	UD	UD	GND
7	UD	UD	UD	UD	UD	GND	UD	UD	UD
8	GND	UD	UD	GND	UD	UD	UD	UD	GND
9	UD	UD	UD	UD	UD	GND	UD	UD	UD
10	GND	UD	UD	GND	UD	UD	UD	UD	GND
11	UD	UD	UD	UD	UD	GND	UD	UD	UD
12	GND	UD	UD	GND	UD	UD	UD	UD	GND
13	UD	UD	UD	UD	UD	GND	UD	UD	UD
14	GND	UD	UD	GND	UD	UD	UD	UD	GND
15	UD	UD	UD	UD	UD	GND	UD	UD	UD
16	GND	UD	UD	GND	UD	UD	UD	UD	GND

5) Current Capability:

▪ +12V	120 A
▪ +12V	120 A
▪ +5V	110 A
▪ -12V AUX	6 A
▪ +12V AUX	6 A
▪ +3.3V AUX	6 A

6) UTILITY (Connector XUTIL)



Connector FCI/Berg 95615-014TRLF

6U Open VPX BACKPLANE
BKP6-DIS05-11.2.16-4


VITA 46
VITA 65



7) JTAG (Connector XJT1)



Consider: JTAG only at Slot 1, Payload slot



8) SYSCON

By setting the signal Syscon to GND the system slot is defined. In general the system slot is slot 1.


There are additional connectors X_SC34, X_SC5 so as you can select any slot as system slot

We offer 2 options for setting:

- Jumper (standard)
- 0 Ohm Resistor for rugged applications

X_SC12

1	SYSCON1
2	GND
3	SYSCON2



9) I2C Connector

There are 2 connectors for system-management I2CA and I2CB.

For customer specific board assembly Zero-Ohm resistors available.

Usable voltages for I2C are 3.3V-AUX

I2CA

1	I2CA_SCL
2	GND
3	I2CA_SDA
4	I2CA_PWR
5	NC

I2CB


1	I2CB_SCL
2	GND
3	I2CB_SDA
4	I2CB_PWR
5	NC

Connector Molex 53398-0571

6U Open VPX BACKPLANE BKP6-DIS05-11.2.16-4	VITA 46 VITA 65	
---	--------------------	--

10) Power Studs M3

The main operating voltages (+12V, +5V) and GND are supplied with M3 screw terminals. The auxiliary operating voltages are supplied via M3 screw terminals. Optimal daughter board supply and trouble-free operation are ensured by the arrangement of the feed modules on the backplane.




11) XBAT

Normally a battery voltage with approximately 3V is available at Pin VBAT of connector VPX-J1. The voltage is externally accessible with connector XBAT, Pin2 or internally using 3.3V_AUX by setting a Jumper between Pin2 and Pin3.

XBAT

1	GND
2	+VBAT
3	+3.3V_AUX




12) NVMRO

If Jumper BR1 is closed NVRMO is set to memory writeable.

BR1

1	NVMRO
2	GND



Germany

Hartmann Electronic GmbH
Phone: +49 711 13 98 90
Fax: +49 711 8 66 11 91
vertrieb.he@kontron.com
www.hartmann-electronic.com

USA

Kontron
Fabian Hemmann
Phone: +1 937-324-2420
Mobile: +1 937 346 7878
fabian.hemmann@us.kontron.com
www.hartmann-electronic.com

France

Kontron Modular Computers S.A.S.
Serge Pichat
Phone: +33 (0)9 66 44 03 15
Mobile: +33 (0)6 82 62 16 00
Serge.pichat@kontron.com
www.hartmann-electronic.com

India

Hartmann Electronic GmbH
Vivek Deshpande
Phone: +1 91 20 66 74 51 23
Vivek.Deshpande@kontron.com
www.hartmann-electronic.com